LT107E-POE

Single Port PoE Injector

The Lamatel LT107E-POE is a Single Port PoE Injector designed to convert standard Ethernet signals into IEEE802.3af-compliant Power over Ethernet (PoE). It enables seamless power and data transmission over a single cable, ensuring stable and reliable connectivity for your PoE-enabled devices such as IP cameras, VoIP phones, and wireless access points. Ideal for small to medium network deployments, this injector simplifies installation while maintaining dependable performance.



Turn OFF signal source and the device's power as installation with power ON may result in damaging the device.

Key Features

- · IEEE802.3af compliant
- Powers one PoE device (up to 15.4W)
- Plug-and-play setup
- Built-in surge protection
- Supports 10/100Mbps
- Compact design

Key Highlights

- Converts standard Ethernet to PoE without requiring a PoE switch
- Ideal for expanding PoE support in legacy networks
- Cost-effective solution for remote device installation
- Quiet, fanless operation for noise-sensitive environments
- LED indicators for power and PoE status monitoring

Applications

- Offices
- Retail
- Homes
- · Schools
- · Remote areas

Applications

Troubleshoot

- 1. Confirm if the installation steps are completed correctly.
- 2. Confirm the RJ45 cable used conforms to the EIT/TIA568A or 568B industry standards.
- 3. The maximum output consumption of the PoE port cannot exceed 15.4W.
- 4. Replace the failing device with a new one to test if the PoE Injector is defective.

Specifications

LT107E-POE	
Power	AC100V ~ AC240V @ 50/60 Hz
Power Rate	≤15.4
Transmission Media	CAT5/5e/6 Cable
Standard	IEEE802.3af
Protection	Wide voltage AC Input, Strong Lightning Protection, ESD, anti- interfere
Structure	Support for Tablet and wallet installation 2 sets of PoE injector can connect with the bayonet
	LT107E-POE
1	Single Port PoE Injector
1	AC Power Line

Installations

- 1. Use a network cable to connect POE IP camera with POE OUT port on your Single Port PoE Injector.
- 2. Use another network cable to connect DATA IN of Single Port PoE Injector with Ethernet switch/other device not supporting PoE.
- 3. Your installation is now ready for Power up: Connect AC Power Line.

